




Connection Diagrams for TRM-CC,
TRM-CB and TRM-CBX Probes




**Connection Diagram:
TRM-CC Probe to
TRM Relay Unit Type-C
(DIN Rail Version)**




Connection Diagram:
 TRM-CB Probe to
 TRM Relay Unit Type-C
 (DIN Rail Version)



Connection Diagram:
TRM-CC Probe to
TRM Relay Unit Type-C
Compact Version



Connection Diagram:
TRM-CB Probe to
TRM Relay Unit Type-C
Compact Version



Connection Diagram:
TRM-CBX Probe to
TRM FLASHER-BE